

ANO-TUFF™ SWIVEL-SEAL HOSE ENDS

HOSE & HOSE ENDS

ANO-TUFF™ HARD ANODIZED ALUMINUM!

EARL'S uses Mil Spec Type III hard anodizing to add superior wear and corrosion resistance to their aluminum. Ideal for use with alcohol fuel and marine environments. Also helps to extend hose end life by reducing thread wear.

EARL'S Ano-Tuff™ Swivel-Seal™ hose ends are offered in a distinctive black hard anodized finish.



SWIVEL-SEAL™ hose ends are designed to be used with Earl's PERFORM-O-FLEX™, AUTO-FLEX™ & PRO-LITE 350™ braid-protected hose. Not intended for use on any other Earl's hose. Use with other manufacturers' hose is not recommended.

HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE	TYPICAL APPLICATION
6	6	6	Fuel Lines
8	8	8	Remote Oil Filter Lines
10	10	10	Dry, Sump, Remote Oil Filter Lines
12	12	12	Dry, Sump, Remote Oil Filter Lines
16	16	16	Dry, Sump & Oil Lines, Radiator Hose



STRAIGHT
AT8001__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT800106ERL	6	6	6
AT800108ERL	8	8	8
AT800110ERL	10	10	10
AT800112ERL	12	12	12
AT800116ERL	16	16	16



30° TUBE
AT8030__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT803006ERL	6	6	6
AT803008ERL	8	8	8
AT803010ERL	10	10	10
AT803012ERL	12	12	12
AT803016ERL	16	16	16



45° LOW PROFILE
AT8045__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT804506ERL	6	6	6
AT804508ERL	8	8	8
AT804510ERL	10	10	10
AT804512ERL	12	12	12
AT804516ERL	16	16	16



45° TUBE
AT8046__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT804606ERL	6	6	6
AT804608ERL	8	8	8
AT804610ERL	10	10	10
AT804612ERL	12	12	12
AT804616ERL	16	16	16



60° TUBE
AT8060__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT806006ERL	6	6	6
AT806008ERL	8	8	8
AT806010ERL	10	10	10
AT806012ERL	12	12	12
AT806016ERL	16	16	16

ANO-TUFF™ SWIVEL SEAL HOSE ENDS

HOSE & HOSE ENDS



90° LOW PROFILE
AT8090__ERL

PART NO.	HOSE END SIZE	USE HOSE SIZE	ADAPTER SIZE
AT809006ERL	6	6	6
AT809008ERL	8	8	8
AT809010ERL	10	10	10
AT809012ERL	12	12	12
AT809016ERL	16	16	16



90° TUBE
AT8091__ERL

Part NO.	Hose End Size	Use Hose Size	Adapter Size
AT809106ERL	6	6	6
AT809108ERL	8	8	8
AT809110ERL	10	10	10
AT809112ERL	12	12	12
AT809116ERL	16	16	16



120° TUBE
AT8120__ERL

Part NO.	Hose End Size	Use Hose Size	Adapter Size
AT812006ERL	6	6	6
AT812008ERL	8	8	8
AT812010ERL	10	10	10
AT812012ERL	12	12	12
AT812016ERL	16	16	16



150° TUBE
AT8150__ERL

Part NO.	Hose End Size	Use Hose Size	Adapter Size
AT815006ERL	6	6	6
AT815008ERL	8	8	8
AT815010ERL	10	10	10
AT815012ERL	12	12	12
AT815016ERL	16	16	16



180° TUBE
AT8180__ERL

Part NO.	Hose End Size	Use Hose Size	Adapter Size
AT818006ERL	6	6	6
AT818008ERL	8	8	8
AT818010ERL	10	10	10
AT818012ERL	12	12	12
AT818016ERL	16	16	16

See pg. 46-50 for AT Adapters

Assembly instructions can be found on pg. 114

tech line: 310-609-1602