

# INNER SPRING, SAFETY WIRE & CAPS/PLUGS

## COMPONENTS AND ACCESSORIES

### ALUMINUM TUBING

ANNEALED ALUMINUM TUBING is easily hand-formed to virtually any requirement. The tubing can be used with Earl's TUBE-MATE AUTO-FIT hose ends, it can be flared and used with Earl's 5818 tube nut and 5819 tube sleeve or an adapter can be welded onto the end(s) of the tube, or the ends can be beaded and used with Earl's ECON-O-FIT hose ends or with standard hose clamps. For clamping hose, tubing should be beaded.

PART NO.	O.D.	LENGTH	FINISH
<del>100031ERL</del>	<del>1/4</del>	<del>10' (3m)</del>	<del>Unanodized</del>
100034ERL	3/8	10' (3m)	Unanodized
100037ERL	1/2	10' (3m)	Unanodized

1/4" TUBE  
DISCONTINUED



### INNER SUPPORT SPRING

IS USED WITH Pro-Lite 350™ hose. A Support Spring is recommended for suction applications or when very tight bends must be made.

Pro-Lite 350™ hose pg. 2

HOSE NO.	4' LENGTH
6	773406ERL
8	773408ERL
10	773410ERL
12	773412ERL
16	773416ERL



### SAFETY WIRE

Earl's safety wire is packaged in a convenient one-pound dispenser. The wire pulls and uncoils from the inside with no tangles. The wire is constructed of Mil-Spec 20995 TYPE 302 Stainless Steel wire.

PART NO.	WIRE (DIA.)	FOOTAGE(APPROX.)
D002ERL	.025	600 ft
D003ERL	.032	350 ft
D004ERL	.041	225 ft



### CAPS & PLUGS

Earl's plastic caps and plugs are great for plugging fittings when hoses are disconnected and for keeping debris from entering hoses when they are being stored.



CAP PART NO.	DESCRIPTION	PLUG PART NO.	QTY. DESCRIPTION	QTY. PER PKG.
179103ERL	Plastic Caps -3	179203ERL	Plastic Plugs -3	25
179104ERL	Plastic Caps -4	179204ERL	Plastic Plugs -4	25
179106ERL	Plastic Caps -6	179206ERL	Plastic Plugs -6	25
179108ERL	Plastic Caps -8	179208ERL	Plastic Plugs -8	15
179110ERL	Plastic Caps -10	179210ERL	Plastic Plugs -10	15
179112ERL	Plastic Caps -12	179212ERL	Plastic Plugs -12	10
179116ERL	Plastic Caps -16	179216ERL	Plastic Plugs -16	10